



OpenWay® CENTRON® Polyphase Meter

Technical Reference Guide

Identification

OpenWay CENTRON Polphase Meter Technical Reference Guide
5 February 2015 TDC-1396-005

Copyright

© 2012-2015 Itron, Inc. All rights reserved.

Confidentiality Notice

The information contained herein is proprietary and confidential and is being provided subject to the condition that (i) it be held in confidence except to the extent required otherwise by law and (ii) it will be used only for the purposes described herein. Any third party that is given access to this information shall be similarly bound in writing.

Trademark Notice

Itron is a registered trademark of Itron, Inc.

All other product names and logos in this documentation are used for identification purposes only and may be trademarks or registered trademarks of their respective companies.

Suggestions

If you have comments or suggestions on how we may improve this documentation, send them to TechnicalCommunicationsManager@itron.com

For more information about Itron or Itron products, see www.itron.com

If you have questions or comments about the software or hardware product, contact Itron Technical Support Services.

Contact

Telephone Support 1-877-487-6602

Email Support support@itron.com

Web/Itron Access support.itron.com

Contents

Revision History	iii
FCC Compliance	iii
FCC Part 15, Class B.....	iii
RF Exposure	iv
Listed Antennas	iv
Professional Installation.....	iv
Modification and Repairs	iv
Canadian Interference Causing Equipment Regulations.....	v
Factory Repair of Meters.....	v
Repair of Meters Under Warranty	v
Repair of Meters Not Under Warranty	v
Service Return Address	v
Recycling Information.....	v

Chapter 1 General Information1

About This Manual	1
General Description.....	1
OpenWay System Overview	2
IPv6 Network.....	2
Network Management.....	3
Field Area Network	3
Connected Grid Router.....	4
C12.22 Network	5
OpenWay Collection Engine (CE).....	5
Collection Engine to Meter Security.....	6
OpenWay RFLAN	7
Priority Network Traffic Handling	8
RFLAN Range Extender	10
RFLAN and Cell Relay Communications.....	10
OpenWay Home Area Network (HAN)	11
HAN Device Mirroring	11
Event Storage	11
Gas Module Configuration	11
Gas Module Firmware Download	12
HAN Join/Rejoin/Disable	12
HAN Multiplier	13
Tiered Pricing.....	13
Residential Inclining Block Pricing.....	13
HAN Security	14
Network Key	14
APS Link Key.....	14
OpenWay Enhanced Security	15
Industrial Defender 300B Security Event Monitoring	15
Certicom AMI 7100 Signing and Encryption Server	16
Certicom AMI 7200 Decryption and Key Update Server	16
C12.22 and Meter Security	16
Security Standards.....	16
Meter Tampering.....	17

Canadian Metering Support	17
Physical Description	18
Meter Components	18
Meter Base	19
Modular Assembly	20
Product Availability	20
Output Options	21
Serial Number	21
Electronic Serial Number	22
Specifications	23
Electrical	23
Characteristic Data	23
Operating Environment	23
Burden Data	24
Technical Data	27
Type Codes	27
Dimensions	28
Shipping Weights	28
Chapter 2 Meter Installation.....	29
Unpacking and Inspection	29
Battery	29
Storage	29
Selecting a Site	30
Installing the Meter into Service	30
Chapter 3 Base Metrology Operation	31
Metrology	31
Form 9S/36S Support	33
Surge Protection	34
Sampling	34
Voltage and Current Measurement	35
Watt-hour (Wh) Measurement	35
VAR-hour (VARh) Measurement	36
Volt-ampere hour (VAh) Measurement	36
Demand Calculations	37
Block Interval Demand Calculation	37
Rolling/Sliding Demand Interval Calculation	38
Thermal Emulation	38
Coincident Demand	39
Power Factor (PF) Calculations	39
Multiple Self Reads	39
KYZ Option Board	40
Chapter 4 OpenWay Polyphase Register Operation	42
Polyphase Basic/Advanced Features	42
Controls and Indicators	43
Liquid Crystal Display (LCD)	43
Load Emulator	45
Optical Port	46
LED Configuration	46
Application of Power and Power-up	46

Demand Functionality	46
TOU/Load Profile Functionality	46
Cold Load Pickup	47
Interval Make-up	47
Registers	47
Energy Quantities.....	47
Demand Quantities	48
Demand Calculations.....	49
Peak Demand (Maximum Demand)	50
Cumulative Demand Values	51
Continuous Cumulative Demand Values.....	51
Present Demand.....	51
Coincident Demand Quantities	51
Power Factor (PF) Calculation.....	52
Operating Modes.....	52
Normal Mode.....	52
Test Mode	53
Display Items.....	54
Energy Data Display Items	54
Demand Data Display Items	54
Instantaneous Data Display Items	55
Informational Data Display Items.....	55
Normal Display Mode.....	56
Error Code Displays	56
Tamper Detection	56
Time Synchronization.....	57
Time of Use (TOU)	57
TOU Schedules.....	57
Calendar Schedule	57
Rates.....	58
Daily Patterns	58
Day Types.....	58
Seasonal Schedules	58
TOU Registers	58
Current Season Registers	58
TOU Operation.....	59
Rate Annunciators and Active Rate Indicators	59
Season Change	59
Critical Peak Pricing	59
Load Profile	59
Load Profile Specifications.....	60
Load Profile Quantities	60
Capacity.....	60
Bit Resolution.....	60
Interval Lengths	60
Power Outage.....	61
Channel Configuration	61
Data Storage	61
Pulse Constants	62
Recording Duration	63
Load Profile Self Reads	63
Extended (Non-Billing) Energy and Load Profile.....	64
Extended Energy and Load Profile Specifications.....	64
Extended Energy and Load Profile Quantities	64

Capacity	64
Bit Resolution	65
Interval Lengths	65
Power Outage	65
Channel Configuration	65
Data Storage	66
Pulse Constants	66
Recording Duration	67
Instrumentation Profile	67
Instrumentation Profile Specifications	68
Instrumentation Profile Capacity	68
Available Quantities	68
Power Outage	69
Read Time Offset	69
Interval Status Codes	69
Voltage Monitoring	71
Interval and Block Data	72
Nominal Voltage Calculation	74
Service Type Handling	75
Threshold Monitoring	75
Reconfiguration	75
Time Adjustment	76
DST Adjustment	76
Test Mode Operation	77
Periodic Read	77
Voltage Monitoring Recording Duration	78
Calculating Voltage Monitoring Size	78
Power Outage Notification (PON) and Restoration (PRN)	79
Outage	79
Restoration	79
Multiple Self Reads	79
Extended Self Read Data	80
Event (History) Log	80
Download Events	90
Security Events	91
Interrogation and Configuration	93
Interrogation	93
Programming	94
Software Support	94
Firmware Upgrades Over the Air	95
Firmware Upgrades Optically	95
Backward Compatibility	96
Asset Synchronization	96

Chapter 5 Testing, Troubleshooting, and Maintenance 98

Recommended Energy Testing Procedures	98
Annunciators	98
Load Indication/Direction Annunciator	98
Phase-Voltage Indication Annunciators	98
Nominal Voltage Indication Annunciator	98
Demand Testing	99
Demand Test Method	99
Demand Calculations	100
Calculation A: Actual Active Energy (kWh)	100
Calculation B: Actual Active Demand (kW)	100

Calculation C: Actual KVA Hours	100
Calculation D: Actual kVA Demand	101
Field Testing	101
Required Hardware	101
Test Method Using Infrared Pulse Adapter	101
Test Method Using a Snap Switch Assembly	101
Visual Indicators	101
Infrared Test LED	101
Troubleshooting	102
Fatal Errors	102
Fatal Error Recovery	102
List of Fatal Errors	104
Non-Fatal Errors	105
List of Non-Fatal Errors	106
Other Issues	107
Incorrect or No Accumulation of kWh or kW	107
Blank Display	107
Time and Date Wrong (TOU Version)	108
On-Site Programmer Cannot Communicate with Meter	108
Maintenance	108
Preventive Maintenance	108
Corrective Maintenance	109
Phasor Diagrams	110
Form 9S 4-Wire Delta	110
Form 9S 4-Wire Wye	111
Form 12S 3-Wire Network	112
Form 16S 4-Wire Delta	113
Form 16S 4-Wire Wye	114
Form 45S 3-Wire Delta	115
Form 45S 3-Wire Network	116
Form 45S 4-Wire Delta	117
Form 45S 4-Wire Wye	118

Appendix A SiteScan On-Site Monitoring System..... 119

SiteScan Service Sense Delay	119
Auto-Service Sensing	119
SiteScan Events	120
Override Auto Service Sensing	121
SiteScan Meter Self-Diagnostic Checks	121
Diagnostic Logging	122
SiteScan System and Installation Diagnostic Checks	122
Meter Services	124
3-Element Transformer Rated (Class 20): 9S	124
2-Element Self Contained (Class 200 and Class 320): 12S	126
3-Element Self Contained (Class 200 and 320): 16S	127
2-Element Transformer Rated (Class 20): 45S(5S)	128
1-Element Self Contained (Class 100): 1S	129
1-Element Self Contained (Class 200 and Class 320): 2S	130
1-Element Transformer Rated (Class 20): 3S	131
1-Element Transformer Rated Contained (Class 20): 4S	132
Phase Indicators	132
Voltage Service Indicator (120, 240, 277, 480)	133
Diagnostic Error Triggering Mechanism (Diagnostics 1 - 4)	133

SiteScan Diagnostic #1 (Cross-Phase, Polarity, and Energy Flow Check)	133
Diagnostic #1 Error Example	135
SiteScan Diagnostic #2 (Phase Voltage Deviation Check)	137
Diagnostic #2 Error Example	138
SiteScan Diagnostic #3 (Inactive Phase Current Check)	140
Diagnostic #3 Error Example	141
SiteScan Diagnostic #4 (Low End Threshold Current)	142
Phase Angle Displacement Check	143
Diagnostic #4 Error Example	144
Appendix B OpenWay HAN Communications	146
Overview	146
Software Support	146
Supported HAN Devices	146
Joining HAN Devices	147
HAN Device Messaging	147
Demand Response and Load Control	148
Securing HAN Communications	148
HAN Event Logs	148
Dynamic Pricing Support	151
Simple Recurring Price	152
Appendix C CENTRON Bridge Polyphase Meter	153
CENTRON Bridge Meter Operation	153
Register Capabilities	153
Energy Registers	154
Demand Registers	154
Bridge Polyphase Meter Forms Supported	154
ChoiceConnect Functionality	155
SCM+ Message Format	155
Demand Reset	155
Tamper and Status Indicators	156
Interval Data	156
Time of Use	157
TOU Schedules	157
Burden Data	158
Enhanced Security	158
ChoiceConnect Enhanced Security	159
Enhanced Security during Transition	159
OpenWay Enhanced Security	159
Supported Systems	160
Field Collection System (FCS)	160
Field Deployment Manager - Endpoint Tools Enhanced	160
OpenWay Tools	160
Itron Security Manager	160
Supported Data Collectors	160
Mobile Collection System (MC3)	161
FC300SR	161
Mobile Collector Lite (MCLite)	161
Transition	161
Field Collection System (FCS)	161
OpenWay Tools	162
OpenWay Functionality	162

Glossary163

Index173